


OSMO Mobile 3

User Manual

v1.0 2019.08



Searching for Keywords

Search for keywords such as “battery” and “install” to find a topic. If you are using Adobe Acrobat Reader to read this document, press Ctrl+F on Windows or Command+F on Mac to begin a search.

Navigating to a Topic

View a complete list of topics in the table of contents. Click on a topic to navigate to that section.


Printing this Document

This document supports high resolution printing.

Using this Manual

Legend


 Important

 Hints and Tips

Download the DJI Mimo App

Scan the QR code or search for ‘DJI Mimo’ on the App Store or Google Play.



 The Android version of DJI Mimo is compatible with Android v6.0 and later. The iOS version of DJI Mimo is compatible with iOS v10.0 and later.

Contents


Using this Manual	2
Legend	2
Download the DJI Mimo App	2
Introduction	4
Overview	4
Getting Started	5
Charging	5
Mounting and Balancing a Mobile Phone	5
Using Osmo Mobile 3	6
Controls and Operations	6
Operation Modes	9
DJI Mimo App	10
Upgrading the Firmware	13
Maintenance	14
Specifications	14
After-Sales Information	15

Introduction

Equipped with 3-axis stabilization OSMO™ Mobile 3 turns your mobile phone into a camera that can deliver a stabilized and super-smooth image. The foldable design makes Osmo Mobile 3 easy to transport and store. Lightweight and ergonomic, Osmo Mobile 3 puts seamlessly smooth video creation at your fingertips.

Osmo Mobile 3 is easy to use and the mobile phone can be manually adjusted by hand in Follow mode. Get creative with features such as Story mode, ActiveTrack 3.0, Hyperlapse, Timelapse, and Pano that are available through the DJI Mimo app.

Overview



- 1. Mobile Phone Holder
- 2. M3x0.5 Screw Hole*
- 3. Tilt Motor
- 4. USB-A Port
- 5. Shutter/Record Button
- 6. USB-C Charging Port
- 7. M Button**
- 8. Joystick
- 9. Battery Level Indicators
- 10. LED Status Indicator
- 11. Pan Motor
- 12. Roll Motor
- 13. Zoom Slider
- 14. 1/4"-20 UNC Port
- 15. Lanyard Hole
- 16. Trigger

* Used for mounting counterweights.

** Used as the power/function button.

Getting Started


Charging

- To charge Osmo Mobile 3, connect a USB adapter (not included) to the charging port using the power cable (included). The battery is fully charged when the battery level indicators turn off.

Charging time: 2.5 hours (when using a 10 W charger)

Max. runtime: 15 hours*

- Connect your mobile phone to the USB-A port. If Osmo Mobile 3 is powered, the mobile phone will begin to charge. If Osmo Mobile 3 is powered off, press the M button once to start charging.




* Max. runtime was tested with the gimbal balanced and held steadily. This value should be taken as a reference only.


Mounting and Balancing a Mobile Phone

Only mount and balance a mobile phone while Osmo Mobile 3 is powered off.


- Make sure the phone holder is vertical before mounting a mobile phone.



- Hold the tilt motor and move the mobile phone left or right until the mobile phone remains balanced when released.



- Hold the tilt motor and move the phone holder left or right until the mobile phone remains balanced when released.




- ⚠ • Make sure the mobile phone is properly installed on the holder and Osmo Mobile 3 and the mobile phone are properly balanced before each use.
- Mount your mobile phone before powering on Osmo Mobile 3. Osmo Mobile 3 will enter standby mode when no mobile phone detected. Press the trigger twice to use Osmo Mobile 3 after mounting a mobile phone.

Using Osmo Mobile 3

Controls and Operations

The buttons on the handle allow greater control over the gimbal and mobile phone. The gimbal converts joystick movements into smooth pan and tilt transitions, and reduces the impact of natural vibrations. In Follow mode, the mobile phone can be adjusted by hand.



1. M Button (Power/Function)



Press and hold to power on. Press and hold until you hear the sound of "beep" to enter/exit standby mode after powering on. Press and hold until you hear the sound of "beep beep" to power off.

Press once: when powered off, press to check the battery level. When powered on, press to switch between photo and video mode or enter or exit the quick menu.

Press twice: switch between landscape and portrait mode.*

Press three times: enter or exit standby mode.

* Landscape and portrait mode can also be switched by adjusting the phone holder directly.

2. Shutter Button

Press once to take photo or start or stop recording. Press and hold for burst shooting when in photo mode.

3. Battery Level Indicators

Indicates the battery level of Osmo Mobile 3. With Osmo Mobile 3 powered off, press the M button once to check the battery level.



4. System Status LED

Indicates the current status of Osmo Mobile 3.

Blinking Pattern	Descriptions
Solid yellow	Bluetooth disconnected
Solid green	Bluetooth connected
Pulses yellow or green	Standby mode
Blinks red and green alternatively	Firmware update required or firmware update failed.
Solid red	Gimbal abnormality (such as temperature is too low or too high, battery is over discharged)

5. Joystick


Move vertically to tilt the mobile phone. Move horizontally to pan the mobile phone. The joystick control direction can be set in DJI Mimo.



When using ActiveTrack 3.0, move the joystick to adjust the camera view.

ActiveTrack 3.0: ActiveTrack 3.0 has been optimized for tracking human subjects with a head and shoulder model or with face detected using deep learning algorithms. The subject will remain in the center of the camera view. The default position is the center of the camera view. Users can also adjust the camera view manually. There are three ways to use ActiveTrack 3.0:

- Drag a box on the screen in the camera view in DJI Mimo. A green box around the subject indicates ActiveTrack 3.0 is successful enabled. Tap the X icon on the top right to stop tracking.
- Enable One-press ActiveTrack in DJI Mimo, and press the trigger once to start or stop ActiveTrack 3.0.
- Enable Gesture Control in DJI Mimo, and then perform a palm or V gesture for one to two seconds when facing the camera. The back camera will detect the nearest head and shoulders and start to track the subject. The front camera will detect the nearest face and start to track the subject.



The differences between the head and shoulder tracking and face track are that head and shoulder tracking supports 360° tracking while face tracking does not. Also, the detection range of the camera are different. The detection range between the back camera and the gesture is 0.5 to 3 m, and the distance between the front camera and the gesture is 0.5 to 2 m.

Note that ActiveTrack 3.0 may increase the power consumption and the temperature of the mobile phone. See the DJI Mimo App section for more information.

6. Zoom Slide

Push up or down to zoom in or out. Push the slider to the T position to enlarge the subject and push the slider to the W position to shrink.



7. Trigger

Press and hold to enter lock mode. In lock mode, the gimbal will not follow the handle movements. Release to exit lock mode.

Press once: when ActiveTrack 3.0 is enabled in Mimo, press to start or stop ActiveTrack 3.0.

Press twice: recenter the gimbal. When using ActiveTrack 3.0, the gimbal will recenter to the center of the camera view.

Press three times: switch between front and back cameras

Press once, and then press and hold: enter Sport mode. Release to exit. In Sport mode, the follow speed of the gimbal increases for capturing quick movements.



8. USB-C Charging Port

Charge the Osmo Mobile 3 by connecting a USB adapter to this port. Refer to the Charging section for more information.

9. USB-A Port

The USB-A port can be used to charge mobile phones.

10. 1/4"-20 UNC Port


The 1/4"-20 UNC port can be used to attach a tripod.

11. Lanyard Hole

The lanyard hole can be used to attach a wrist strap.

12. Combination Operation

Press the M button, shutter button, and trigger simultaneously to reset the Bluetooth connection.

 Osmo Mobile 3 will be powered off automatically if there is no operation for 10 minutes in standby mode.

Operation Modes

The figures below depict the operation modes when using Osmo Mobile 3 in landscape mode. The same operation modes apply when used in portrait mode.

Upright Mode


Upright mode can be used without any further user input. In this mode, press the M button twice quickly to center the mobile phone.

Underslung Mode


Hold Osmo Mobile 3 upside down to enter Underslung mode, in which the mobile phone can easily capture images from a lower position.

Side Grip Mode


Rotate Osmo Mobile 3 to the right or left by 90° to go from Upright to Side Grip mode.




Upright Mode



Underslung Mode





Side Grip Mode


-  • Due to sensor noise, the handle may vibrate slightly when the gimbal is moving. This phenomenon is normal and does not affect shooting stability.
- Note that in Follow mode, to make sure the gimbal can be centered quickly and resume tracking, the mobile phone will be within $\pm 3^\circ$ of the true center after re-centering. The joystick can be used to fine-tune the position of the mobile phone.

DJI Mimo App


Watch a live HD video feed on your mobile screen through the DJI Mimo app. The app also allows you to use the Story mode, Hyperlapse, Timelapse, ActiveTrack 3.0, and Pano, or configure camera and gimbal settings in just a few taps.



 Camera View: tap to connect to Osmo Mobile 3. Once connected, DJI Mimo enters camera view.

 Home: tap to return to Home.


 Edit: tap to edit photos or video from Osmo Mobile 3 or import and edit from a mobile device.

 Profile: register or log in to a DJI account. View works and settings, check likes and followers, send messages to other users, and connect with the DJI Store.

 Academy: tap to watch tutorials and manuals.

Connecting to the DJI Mimo App

1. Power on Osmo Mobile 3.
2. Enable Bluetooth on the mobile phone, and connect the device with an OM3 prefix name in Mimo.
3. When using Osmo Mobile 3, activation is required using DJI Mimo. Follow the instructions to activate.
4. Enter camera view after activation is complete.

 When connected via Bluetooth, Osmo Mobile 3 is able to control the camera of the mobile phone without DJI Mimo. This feature is available with a mobile phone which supports camera control using the volume button.

DJI Mimo App Settings

Camera View



1. Home

🏠 : Tap to return to home page.

2. Gimbal Battery Level

🔋🌀 : Displays the current battery level of the gimbal.

3. Mobile Phone Battery Level

🔋 : Displays the current battery level of the mobile phone.

4. Flash

⚡ : Displays the flash status.

5. Gimbal Mode

🌀 : Display the current gimbal mode: Follow, Tilt Locked, and FPV.

6. Story Mode

📽 : Story mode provides several templates for recording video. When you are finished shooting, a video will be generated automatically according to the selected shooting template.

7. Front/Back Camera Switch

📷 : Tap to switch between the front and back cameras of your mobile phone.

8. Shutter Button

⦿ : Tap to take a photo or to start or stop recording video.

9. Shooting Mode

Scroll to select the shooting mode. Choose between Hyperlapse, Timelapse, Slow Motion, Video, Photo, Pano, and Story mode.

Hyperlapse: enable to shoot a Timelapse photo while moving the mobile phone. Tap the shutter button to begin.

Timelapse: there are two types of Timelapse, Position and Path. After selecting the Timelapse, tap the settings at the top of the screen. For Position Timelapse, set the interval and duration time and start to shoot. For Path Timelapse, up to four positions can be selected, and then the gimbal will travel through the positions in order.

- Slow Motion: tap to shoot video at 8x slow motion (only iOS supports).
- Video: tap to shoot a normal video. Press and hold for burst shooting.
- Photo: tap to take a single shot or interval photo.
- Pano: tap to take a 3x3 or 180° panorama photo.
- Story: Refer to Number 6 for more information about Story mode.


10. Playback

 : Tap to preview photos and videos.

11. Settings ●●●

 : Shooting Mode Settings

Shooting Mode	Settings
Hyperlapse	Flash, White Balance, Grid, One-press ActiveTrack
Timelapse	Flash, White Balance, Grid
Slow Motion	Flash, White Balance, Grid, One-press ActiveTrack
Video	Flash, White Balance, Grid, One-press ActiveTrack, Gesture Control
Photo	Flash, White Balance, Grid, One-press ActiveTrack, Gesture Control
Pano	Flash, White Balance, Grid, Save Unstitched Pano Photos

 Gimbal Settings

Follow Mode:

- a. Follow: pan and tilt axes follow.
- b. Tilt Locked: only the pan axis follows.
- c. FPV: pan, tilt, and roll axes follow.

Sport Mode Switch: tap to enable or disable Sport mode.

Zoom Speed: tap to set the zoom speed when using the zoom slider.

Joystick Speed: tap to set the maximum speed when controlling the joystick. There are Fast, Medium, and Slow options.

Joystick Control Direction: choose from Free and Horiz/Vert. Free enables the gimbal to be controlled in 360°. Horiz/Vert enables the gimbal to be controlled in a horizontal or vertical direction.

Invert Pan Control: after enabling this feature, the pan axis movement direction is the reverse of the joystick direction.

Invert Tilt Control: after enabling this feature, the tilt axis movement direction is the reverse of the joystick direction.

Press M Button: define the feature when pressing the M button once. Select from switching between photo and video mode or enter or exit quick menu.

Gimbal Auto Calibration: reduces drift caused by nearby magnetic interference or human error. Do not touch the gimbal and hold Osmo Mobile 3 still and upright during calibration.

 General Settings

Device Management, Device Name, Firmware Version and SN.

12. Camera Settings

Shooting Mode	Settings
Hyperlapse	Resolution and FPS*, Speed, ISO, Shutter, and EV*
Timelapse	Resolution and FPS*, Speed, ISO, Shutter, and EV*
Slow Motion	ISO, Shutter, and EV*
Video	Glamour Effects**, Resolution and FPS*, Speed, ISO, Shutter, and EV*
Photo	Glamour Effects, Count Down, ISO, Shutter, and EV*
Pano	3x3 and 180° Pano, ISO, Shutter, and EV*

* FPS, ISO, Shutter and EV settings are only available for iOS devices.

** When enabling Glamour Effects, the video resolution is set to 720p.

Zooming

Place two fingers on the screen and move them apart to zoom in or move them together to zoom out. Note that zooming is only available when in metering mode and using the rear camera of your camera.

Upgrading the Firmware

Use the DJI Mimo app to update the Osmo Mobile 3 firmware. It takes approximately three minutes to complete an update.

How to Update

Make sure that the battery level is at least 15% (with two battery level indicators light up) before starting an update. Connect Osmo Mobile 3 to your mobile device and launch DJI Mimo. You will be prompted if a new firmware update is available. To start updating, connect your mobile device to the internet and follow the on-screen instructions.

Do not exit DJI Mimo while updating the firmware. Pay attention to on-screen prompts. The LED Status Indicator will blink green and red alternatively and become solid green once the firmware update has completed successfully.


If an update is unsuccessful, restart Osmo Mobile 3 and DJI Mimo, and reconnect the Bluetooth, and then retry.

Maintenance

Osmo Mobile 3 is designed to be folded for easier storage and transportation.

Rotate the pan and tilt axis to align with the marks on the gimbal, and then fold Osmo Mobile 3. Note that the hole on the pan motor should be matched with the marker on the arm.

Osmo Mobile 3 will enter storage mode after powered off by pressing the M button, fold it directly.



Specifications

Name	OSMO MOBILE 3
Model	OF100
Dimensions	Unfolded: 285×125×103 mm Folded: 157×130×46 mm
Weight	405 g
Consumption	1.2 W (steady and balanced status)
Mechanical Range	Pan: -162.5° to 170.3° Roll: -85.1° to 252.2° Tilt: -104.5° to 235.7°
Max Controllable Speed	120°/s
Compatible Phones	Weight: 200 ± 30 g Dimension: Diagonal ≤ 180 mm (or ≤ 7.08 in) Thickness ≤ 9.5 mm Width: 62-88 mm
Mode	Bluetooth Low Energy 5.0
Transmitter Power (EIRP)	≤4 dBm
Operation Frequency	2.400-2.4835 GHz
Type	18650 Li-ion
Capacity	2450 mAh
Energy	17.64 Wh
Voltage	7.2 V
Charging Temperature	5° to 40° C (41° to 104° F)
Operating Temperature	0° to 40° C (32° to 104° F)

Charging Time	2.5 hours (Measured with a 10W charger)
Operating Time	15 hours (Under ideal conditions with the gimbal fully balanced)

After-Sales Information

Visit <https://www.dji.com/support> to learn more about after-sales service policies, repair services, and support.



For online support, please scan this code
with Facebook Messenger

This content is subject to change.

Download the latest version from
www.dji.com/osmo-mobile-3

OSMO is a trademark of DJI.
Copyright © 2019 DJI OSMO All Rights Reserved.